
YIOSI

INSTALLATION GUIDE

Blake Picture Light 30"

PICTURE LIGHT · WALL MOUNT



Model **YIOSI-0522**

Please read this guide completely before you begin, and keep it for future reference.

BEFORE YOU BEGIN

⚠ **WARNING**

- **Turn off the power at the circuit breaker** before installing, changing bulbs or cleaning the fixture.
- Installation by a **qualified electrician** is recommended. Install in accordance with local electrical codes.
- This fixture uses 4 E12 bulbs, 4 W each (included). Replace only with bulbs of the same type and rating.
- Do not clean the fixture with corrosive substances such as gasoline or alcohol-based disinfectants.
- Use this fixture only for its intended purpose. Do not modify or rewire it.
- Keep small parts and packaging away from children. They can cause serious injury.

PREPARATION


- Read every step carefully and follow them in order.
- Unpack and check all parts against the parts list. If anything is missing or damaged, contact us before installing (see the last page). We will send replacement parts promptly.
- Assemble the fixture where it will be installed. Moving it mid-assembly risks losing small parts.

SPECIFICATIONS

LIGHT SOURCE	WATTAGE	COLOR TEMPERATURE
4 × E12 bulbs (included)	**4 W per bulb**	**2700K**


IN THE BOX






PART	QTY	DESCRIPTION
A	× 1	Picture light (lamp body)
B	× 4	E12 bulb
—	× 1	Gloves
—	× 6	Wire connector
—	× 8	Screw
—	× 8	Wall anchor
—	× 6	Machine screw

PACKAGING






The fixture ships in one layer: lamp body, bulbs and accessory kit.

INSTALLATION

STEP 1

Mount the plate


Turn off the power at the circuit breaker. Take the mounting plate off the fixture and fix it to the wall junction box with the screws (use the wall anchors where needed).



STEP 2

Connect the wires


Join the fixture wires to the matching house supply wires with the wire connectors: live to live, neutral to neutral, ground to ground. Tuck the connections neatly into the junction box.



STEP 3

Attach the fixture


Place the fixture over the mounting plate and fasten it securely with the screws.



STEP 4

Fit the bulbs and aim the shade

Screw the four E12 bulbs (B) into the lamp holders. Tilt the shade to the angle you want, then tighten the screw by hand to hold it. Restore power and switch on to test.



CARE & SUPPORT

CLEANING & CARE

- Clean the fixture about once a month to keep it looking its best.
- Turn off the power and let the fixture cool to room temperature first.
- Wipe with a soft cloth dampened with water and wrung dry. Never spray liquid directly onto the fixture.
- Do not use gasoline, alcohol or other corrosive cleaners.

GOOD TO KNOW

- Use the fixture only as designed. Damage caused by modification, third-party parts or natural disasters is not covered.
- Warranty terms are listed at yiosilamp.com.

NEED HELP?

support@yiosilamp.com

+1 970-896-9411

Missing parts, installation questions or anything else, we are here to help. Please include your order number and a photo of the issue so we can resolve it quickly.