
YIOSI

INSTALLATION GUIDE

Combined Marble Slice Round Pendant Chandelier

CHANDELIER · CEILING MOUNT



Model **YIOSI-0722**

Please read this guide completely before you begin, and keep it for future reference.

BEFORE YOU BEGIN

⚠ **WARNING**

- **Turn off the power at the circuit breaker** before installing, changing bulbs or cleaning the fixture.
- Installation by a **qualified electrician** is recommended. Install in accordance with local electrical codes.
- Integrated LED, 24 W. No bulbs to replace.
- Do not clean the fixture with corrosive substances such as gasoline or alcohol-based disinfectants.
- Use this fixture only for its intended purpose. Do not modify or rewire it.
- Keep small parts and packaging away from children. They can cause serious injury.


PREPARATION

- Read every step carefully and follow them in order.
- Unpack and check all parts against the parts list. If anything is missing or damaged, contact us before installing (see the last page). We will send replacement parts promptly.
- Assemble the fixture where it will be installed. Moving it mid-assembly risks losing small parts.
- This guide shows one size. Other sizes in the same series install the same way.

SPECIFICATIONS

LIGHT SOURCE	WATTAGE	MOUNTING
Integrated LED	**24 W**	**Ceiling, adjustable cables**

IN THE BOX




PART	QTY	DESCRIPTION
A	× 1	Mounting bracket
B	× 4	Screw
C	× 3	Wire connector
D	× 1	Fixture ring with canopy
E	× 4	Cable gripper
F	× 20	Marble slice
G	× 20	Marble slice
H	× 40	Slice screw

INSTALLATION

STEP 1

Mount the bracket and connect


Turn off the power at the circuit breaker. Remove the mounting bracket (A) from the canopy and fix it to the ceiling junction box with the screws (B). Join the fixture wires to the matching house supply wires with the wire connectors (C): live to live, neutral to neutral, ground to ground.



STEP 2

Set the height and secure


Adjust the hanging cables to the height you want, then lift the canopy up to the bracket and fasten it in place.



STEP 3

Fit the marble slices

Fix the marble slices (F, G) to the ring with the screws (H), alternating the two types as shown. To change the height later, press the small pin into the canopy and slide the cable. Restore power and switch on to test.



CARE & SUPPORT

CLEANING & CARE

- Clean the fixture about once a month to keep it looking its best.
- Turn off the power and let the fixture cool to room temperature first.
- Wipe with a soft cloth dampened with water and wrung dry. Never spray liquid directly onto the fixture.
- Do not use gasoline, alcohol or other corrosive cleaners.

GOOD TO KNOW

- Use the fixture only as designed. Damage caused by modification, third-party parts or natural disasters is not covered.
- Warranty terms are listed at yiosilamp.com.
- Natural stone varies piece to piece. Veining and tone differences are part of its character.

NEED HELP?

support@yiosilamp.com

+1 970-896-9411

Missing parts, installation questions or anything else, we are here to help. Please include your order number and a photo of the issue so we can resolve it quickly.