
YIOSI

INSTALLATION GUIDE

Bubble Glass Pendant

PENDANT · CEILING MOUNT



Model **YIOSI-0889**

Please read this guide completely before you begin, and keep it for future reference.

BEFORE YOU BEGIN

⚠ **WARNING**

- **Turn off the power at the circuit breaker** before installing, changing bulbs or cleaning the fixture.
- Installation by a **qualified electrician** is recommended. Install in accordance with local electrical codes.
- This fixture uses 1 E26 bulb (4 W, 2700K, included). Replace only with a bulb of the same rating.
- Do not clean the fixture with corrosive substances such as gasoline or alcohol-based disinfectants.
- Use this fixture only for its intended purpose. Do not modify or rewire it.
- Keep small parts and packaging away from children. They can cause serious injury.


PREPARATION

- Read every step carefully and follow them in order.
- Unpack and check all parts against the parts list. If anything is missing or damaged, contact us before installing (see the last page). We will send replacement parts promptly.
- Assemble the fixture where it will be installed. Moving it mid-assembly risks losing small parts.

SPECIFICATIONS

LIGHT SOURCE	WATTAGE	COLOR TEMPERATURE
1 × E26 bulb (included)	**4 W**	**2700K**

IN THE BOX



PART	QTY	DESCRIPTION
A	× 1	Canopy
B	× 4	Glass hook (incl. 1 spare)
C	× 1	Bubble glass shade
D	× 1	E26 bulb
E–G	× 1 ea.	Chains: 12" (E), 20" (F), 39" (G)
H	× 1	Light body (boom)
—	× 1 set	Mounting hardware: screws, anchors, chain links, wire connectors

INSTALLATION

STEP 1

Attach the chain


Join the light body (H) to the canopy (A) with a chain (E, F or G) and the chain links.



STEP 2

Mount and connect

Turn off the power at the circuit breaker. Fix the mounting plate to the ceiling with the screws and anchors. Join the fixture wires to the matching house supply wires with the wire connectors: live to live, neutral to neutral, ground to ground. Hang the fixture from the plate and fasten the canopy.



STEP 3

Fit the bulb and glass

Screw in the E26 bulb (D). Clip the hooks (B) onto the rim of the glass shade (C) and hang it on the light body. Restore power and switch on to test.



CARE & SUPPORT

CLEANING & CARE

- Clean the fixture about once a month to keep it looking its best.
- Turn off the power and let the fixture cool to room temperature first.
- Wipe with a soft cloth dampened with water and wrung dry. Never spray liquid directly onto the fixture.
- Do not use gasoline, alcohol or other corrosive cleaners.

GOOD TO KNOW

- Use the fixture only as designed. Damage caused by modification, third-party parts or natural disasters is not covered.
- Warranty terms are listed at yiosilamp.com.

NEED HELP?

support@yiosilamp.com

+1 970-896-9411

Missing parts, installation questions or anything else, we are here to help. Please include your order number and a photo of the issue so we can resolve it quickly.